LUXUL switch configuration

Model number：LUXUL AMS-4424P

Configuration method：Web（http://192.168.0.4 Account: admin

Password: admin）

1. 1. Set the IP of the wired network card of the computer: 192.168.0.20, subnet mask: 255.255.255.0, and

   Connect all the wired network ports to any port of the switch with a network cable.

2. Open the switch setting page on the browser, http://192.168.0.4

   Account: admin. Password: admin.。



3. Restore the switch to factory settings, click the menu Administration->Factory Defaults, click Yes, and wait for a few seconds for the operation to complete.





4. Click the menu Configuration->IPMC->IGMP Snooping->Basic Configuration to enter the IGMP Snooping configuration page.



5. Select

    1. Snooping Enabled

    2. Leave Proxy Enabled

    3. All Ports Fast Leave



6. Scroll to the bottom and click Save.。



7. Click Administration->Configuration->Save startup-config，click Save Configuration





8. Reboot the switch.